


A quick and simple procedure that refills your master cylinder reservoir and/or hydraulic clutch reservoir with new fluid when bleeding a hydraulic system. Fluid feeder adapter fits most pint and quart brake fluid bottles (1-1/4" wide mouth). Also Included are three master cylinder reservoir adapter plates.

INSTRUCTIONS

For replacing old fluid with new when bleeding your system:

1. Screw feeder adapter onto brake fluid bottle.
2. Select the appropriate master cylinder plate and place it on top of the master cylinder reservoir.
3. Invert bottle of fluid with feeder adapter attached and insert feeder adapter into hole in the master cylinder plate. Push down on the feeder adapter until locks into the feeder plate (see illustration).
4. Bleed the hydraulic system as recommended by the manufacturer.

NOTE: Take care when inserting and removing brake fluid bottle to avoid spillage.



www.mityvac.com

LINCOLN INDUSTRIAL STANDARD WARRANTY

LIMITED WARRANTY

Lincoln warrants the equipment manufactured and supplied by Lincoln to be free from defects in material and workmanship for a period of one (1) year following the date of purchase, excluding therefrom any special, extended, or limited warranty published by Lincoln. If equipment is determined to be defective during this warranty period, it will be repaired or replaced, within Lincoln's sole discretion, without charge.

This warranty is conditioned upon the determination of a Lincoln authorized representative that the equipment is defective. To obtain repair or replacement, you must ship the equipment, transportation charges prepaid, with proof of purchase to a Lincoln Authorized Warranty and Service Center within the warranty period.

This warranty is extended to the original retail purchaser only. This warranty does not apply to equipment damaged from accident, overload, abuse, misuse, negligence, faulty installation or abrasive or corrosive material, equipment that has been altered, or equipment repaired by anyone not authorized by Lincoln. This warranty applies only to equipment installed, operated and maintained in strict accordance with the written specifications and recommendations provided by Lincoln or its authorized field personnel.

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

In no event shall Lincoln be liable for incidental or consequential damages. Lincoln's liability for any claim for loss or damages arising out of the sale, resale or use of any Lincoln equipment shall in no event exceed the purchase price. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, therefore the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that vary by jurisdiction.

Customers not located in the Western Hemisphere or East Asia: Please contact Lincoln GmbH & Co. KG, Walldorf, Germany, for your warranty rights.

Lincoln Industrial Contact Information

To find Lincoln Industrial's Nearest Service Center call the following number, you may also use our website.

Customer Service 314-679-4200
Website: www.lincolnindustrial.com